



品番 DK033550	商品 置き型洗面ボウル	お問合せ先 カネジン 〒111-0042 東京都台東区寿3-7-9 TEL:03-5811-1740 FAX:03-5811-1741	
ブランド DURAVIT (Foster)	縮尺	日付 2016.08.18	
備考 オーバーフロー付			



Schrauben müssen fest angezogen werden um Undichtigkeiten zu vermeiden.

The screws must be firmly tightened to prevent leaks.

Serrer les vis à fond pour assurer une parfaite étanchéité.

Draai de schroeven stevig aan om lekkage te voorkomen.

I dadi devono essere serrati a fondo per garantire i viti stagna.

Los tornillos deben ser fuertemente apretados para evitar pérdidas de agua.

Os parafusos deverão ser firmemente apertados para evitar fugas.

Sızdırmazlığı sağlamak için, montaj vidaları kuvvetlice sıkılmalıdır.

螺丝钉必须拧紧, 以防渗漏。

